

## Assembly Instructions for RootBuilder® Kits

(High 5® is pictured, but assembly is the same)



1. Insert the root directing bottom (smooth side down) into the bottom row of the RootBuilder® slots (holes should be pointing downward).



2. Wrap RootBuilder® around the root directing bottom.



3. Insert a cable tie\* into the hole at the bottom on the outside of the RootBuilder®.



4. Move up two holes and reinsert the cable tie\*. Pull through to the outside and tie off.



5. Repeat steps 3 and 4 for the upper cable tie.



6. Cut the ends of the cable ties to finish the assembly.

\*White latches can be used vertically or horizontally to secure through two holes.